



Spillover Spa Winterizing Instructions

Winterizing instructions for spillover spas installed in high water table sites:

1. Drain the vessel.
2. Remove all jet nozzles with the special jet wrench tool supplied when the vessel was delivered.
3. Blow out all return lines with a blower. Once completely drained cap off all lines with winterizing plugs.
4. Remove all the main drain caps using a Phillips screw driver to remove 4 screws on each cap. Blow out the suction lines using a blower till completely drained. Cap off all 4 openings with main drain winterizing plugs.
5. It's recommended that you use a large piece of vinyl or heavy-duty tarp to drape the inside of the vessel and use water bags to secure it to the deck. Next fill the vessel up 3/4 of the way with water to give you secure weight inside the vessel to prevent ground water conditions from shifting the vessel.

For non high ground water conditions:

1. Follow steps 1-4 above.
2. Even in low water table areas you can follow step 5 above OR put a 4'x4' winter air pillow inside the vessel and leave the vessel empty of water. Once the winter air pillow is in place cover the vessel with a heavy-duty tarp and secure it on the deck using water bags.

* If you do not have a special wrench jet tool you can order it from your distributor.
It's a Waterway Jet Wrench 218-1770.

